



COMPATIBILITY: QTV
IRV / VLV
NI
DA
FBLV
FCMV
FMEV

003..
008..
010..
001..



1


Montaggio Assembly



$65 \pm 5^{\circ}\text{C}$



$15 \pm 5^{\circ}\text{C}$




MIN - MAX



OK

2 a

010
003
008
001




b

003
008




CALDO
HOT



FREDDO
COLD




3







4

QTV




010
003
008
001




FCMV
FMEV

5



010
003
008
001


G 1/2"



003
008
001

F


Funzionamento
Working



010
003
008
001

D


Deviatore
Diverter



001

M

Manutenzione
Service






Sostituzione Vitone Ceramico

How to replace Ceramic Disc Valve

a



010
003
008
001

b

Sostituzione Aeratore

How to replace Aerator

